

S056 Ulanzi MT-44 B 双子星三脚架说明书

材质:100g书纸, 双面单色印刷
印刷颜色:80%K
成品尺寸:80*100mm
展开尺寸:240*300mm
成型工艺:十字折
尺寸公差:±1mm
注:所有成品及辅料符合欧盟包装指令94/62/EC, 美国TPCH, 欧盟REACH, TSCA, POPs法规

- 裁切线
— 折痕线
— 出血线



蓝牙功能说明

功能	说明
开机/关机	长按拍照键2秒
拍照/家视频	单击拍照键
初次连接	开色温控制, 指示灯闪烁进入配对状态; 手机搜索 "Ulanzi MT-44 B" 匹配, 配对成功后, 指示灯熄灭
未连接状态下	5分钟无操作自动关机 (重复按拍照键开机)
自动连接	开机可自动连接已配对手机
休眠	5分钟无操作将自动休眠
休眠唤醒	休眠状态短按拍照键, 指示灯闪一次后进入配对模式
蓝牙距离	≤10米

注意: 蓝牙连接断开后将进入配对状态, 当设备重新进入<10米范围内时, 蓝牙将自动重连。

蓝牙指示灯灯效说明

功能	指示灯状态
开机	蓝灯快闪
关机	蓝灯快闪后熄灭
拍照	蓝灯快闪一次
配对成功	蓝灯熄灭
配对模式	蓝灯闪烁
休眠状态	蓝灯熄灭

CN

Bluetooth Function Description

Function	Manual
Power On/off	Long press photo key 2s
Photo / Video	Click photo key
First Connection	Turn on remote, indicator blinks to pairing mode, phone searches "Ulanzi MT-44 B" to pair, indicator off after success.
Disconnected State	Auto off after 5 min idle (press power to restart)
Auto Connect	Auto connect to paired phone on power on
Sleep	Sleep after 5 min idle
Wake From Sleep	Short press photo key in sleep to pair (indicator blinks)
Bluetooth Range	<10m

Note: If Bluetooth is disconnected, it enters pairing mode. When back within <10m, it reconnects automatically.

Bluetooth indicator light guide

Function	Indicator Status
Power On	Blue light fast flash
Power Off	Blue light fast flash then off
Photo	Blue light flashes once
Paired	Blue light off
Pairing	Blue light blinks
Sleep	Blue light off

EN

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

EN

Bluetooth情報

機能	説明書
オン/オフ	撮影ボタン長押し2秒
写真/動画	撮影ボタンクリック
初回接続	リモコンをオンにすると、インジケータが点滅しペアリングモードに。スマホで「Ulanzi MT-44 B」を検索し、ペアリング成功後、インジケータが消灯
未接続状態	5分操作なしで自動電源オフ (撮影ボタンで起動)
自動接続	起動時にペアリング済みのスマホに自動接続
スリープ	5分操作なしで自動スリープ
スリープ解除	スリープ中に撮影ボタン短押しで、インジケータが1回点滅しペアリングモードへ
Bluetooth距離	≤10m

注意: Bluetooth接続が切れるとペアリング待機状態になります。デバイスが10m以内にると自動再接続されます。

Bluetoothインジケータ表示説明

機能	インジケータ状態
起動	青点滅 (高速)
電源オフ	青点滅後に消灯
撮影	青が1回点滅
ペアリング成功	青消灯
ペアリング中	青点滅
スリープ	青消灯

JP